

EZ-MARKER INSTRUCTION SHEET

Figure 1. Fold the color band in half with the colors facing outward.

Figure 2. Open the EZ-MARKER housing and position the fold of the color band over the open slot with the colors facing down.

Figure 3. Snap in one side of the color band into one side of the EZ-MARKER housing.

Figure 4. Force the fold of the color band into the slot of the EZ-MARKER housing.

Figure 5. Snap in the other side of the color band into the other side of the EZ-MARKER housing.

Figure 6. Clamp the EZ-MARKER housing around the cord using the tie wrap function built into the housing and then clip the tails off.



Figure 1.



Figure 2.



Figure 3.



Figure 4.



Figure 5.



Figure 6.